



孕龍科技股份有限公司
ZeroPlus Technology Co., Ltd.

SPECIFICATION

MODEL: B12006-DP AUX Channel 1.1

PART NO: _____

VERSION: V1.00

Approver		Check	Design
GM	PM		

Customer Confirm

*Please fax the file to ZeroPlus Technology after signing.

2F, NO.123, Jian Ba Rd,
Chung Ho City, Taipei Hsian, R.O.C.

Tel: +886-2-66202225
Fax: +886-2-22234362



Content

1. Software Register	3
2. User Interface	7
3. Operating Instructions	10




1 Software Register

Please register the software as the following steps:


※ Remark1: The registration steps for all protocol analyzers are the same; you can complete the registration by following procedures. Following is an example on how to register the Protocol Analyzer BUS.

※ Remark2: We won't have additional notice for you, when there is any modification of the module specification. If there is some unconformity caused by the module version upgrade, users should take the module software as the standard.


STEP 1. Open the Logic Analyzer and group the unanalyzed channels into **Bus1** by pressing the **Right Key**.




STEP 2. Select **Bus 1**, then press **Right Key** on the mouse to list the menu, then press **Bus Property** or **Bus** icon on the toolbar to open **Bus Property** dialog box.



STEP 3. Select the Protocol Analyzer, and then choose **ZEROPLUS LA BUS MODULE V1.00.00 (CN01)**. Next click Parameters Configuration to open Protocol Analyzer Bus dialog box.




STEP 4. Press Register tab to type the serial key number of BUS. Then press Register.






STEP 5. After pressing the Register button, following dialog box will appear, it denotes that the BUS has been registered successfully.



2 User Interface

Please refer to the below images to do settings of DP AUX Channel 1.1 module.

DP AUX Channel 1.1 Configuration dialog box



Pin Assignment

Protocol Analyzer DP AUX Channel 1.1 only needs one channel to decode, which is A0 by default.

Decoding DPCD

Decode in the DPCD form. It is not selected by default.


Sampling Position

There are 0%, 5%, 10%, 15%, 20%, 25%, 30%, 35%, 40%, 45%, 50%, 55%, 60%, 65%, 70%, 75%, 80%, 85%, 90%, 95% and 100% to select; it is 50% by default.

Protocol Analyzer Color


The color can be varied by users.

DP AUX Channel 1.1 Packet dialog box



In the Packet part, users can select the items to be displayed and their colors as their requirements.


DP AUX Channel 1.1 Data Format dialog box



Users can set the Address, Length, Data and CMD as their requirements. When selecting the option Activate,

the data format is decided by the settings in the Protocol Analyzer; when not selecting the option Activate, the data format is decided by the settings in the main program.


DP AUX Channel 1.1 Register dialog box




There is ZeroPlus company information. If you have questions about software operations, you can contact ZeroPlus by Telephone or Email.

3 Operating Instructions


STEP 1. Group A0 into **Bus1** by pressing the **Right Key** on the mouse. DP AUX Channel 1.1 needs at least one channel to decode signal, so it is necessary to group one or more channels into the Bus.




STEP 2. Select **Bus1**, press right key and select **Bus Property** from the popped menu, or click the **Bus** icon on the toolbar, to open the **Bus Property** dialog box.




STEP 3. Select Protocol Analyzer, and select ZEROPLUS LA DP AUX Channel 1.1 V1.00.00(CN01). Then click Parameters Configuration to open the Configuration dialog box.




STEP 4. Set the Pin Assignment.



STEP 5. Set the Decoding DPCD.




STEP 6. Set the Sampling Position.






STEP 7. Set the Protocol Analyzer Color



STEP 8. Following pictures show the completion of the protocol analyzer decoding and the packet list. The trigger condition is set as Rising Edge, the memory depth is 1M and the sampling frequency is 10MHz (the sampling frequency should be more than four times higher than the signal to be tested).

Protocol Analyzer Decoding





Packet List

